



ASSEMBLY INSTRUCTION

MODEL : TF-2S32-H


Hand Crank Height Adjustable Table Frame
(4 & 5 Feet Length)




Component List - TF-2S32-H




Left Column
Qty:1




Right Column
Qty: 1




Foot
Qty: 2




Stand L Plate Left
Qty: 2



Stand L Plate Right
Qty: 2




Side L Plate
Qty : 2




Front L Plate
Qty: 2




Hex Shalf L175mm
Qty : 1




Hex Shalf L430mm
Qty : 2



Axle Drive L300mm
Qty : 1




Axle Drive L800mm
Qty : 1




Screw M5
Qty : 32




Screw M6 X L16
Qty : 8




Leveling Base
Qty: 4



Axle DriveHolder
Qty : 2



Tapping Screw
5 X L30
Qty : 4




Crank Handle
Qty : 1

Assembly Instruction: Left Stand Assembly


Step 1 : Install Leveling Base

ITEM NO.	DESCRIPTION	QTY.
1	Foot	1
2	Leveling Base	2




STEP 2 : Install Foot

ITEM NO.	DESCRIPTION	QTY.
3	Left Column	1
4	Screw M6	4




DETAIL C
SCALE 1 : 5



STEP 3 : Install Stand L Plate


ITEM NO.	DESCRIPTION	QTY.
5	Stand L Plate Right	1
6	Stand L Plate Left	1
7	Screw M5	8



Assembly Instruction: Right Stand Assembly


Step 1 : Install Leveling Base

ITEM NO.	DESCRIPTION	QTY.
1	Foot	1
2	Leveling Base	2




STEP 2 : Install Foot

ITEM NO.	DESCRIPTION	QTY.
3	Right Column	1
4	Screw M6	4




DETAIL E
SCALE 1 : 5



STEP 3 : Install Stand L Plate


ITEM NO.	DESCRIPTION	QTY.
5	Stand L Plate Right	1
6	Stand L Plate Left	1
7	Screw M5	8



Assembly Instruction: Integrate Left & Right Stand


4 Feet Model

ITEM NO.	DESCRIPTION	QTY.
1	Left Stand Assy	1
2	Right Stand Assy	1
3	Front L Plate	2
4	Screw M5	8



5 Feet Model


ITEM NO.	DESCRIPTION	QTY.
1	Left Stand Assy	1
2	Right Stand Assy	1
3	Front L Plate	2
4	Screw M5	8



Assembly Instruction : Install Axle Drive & Side L Plate (4 Feet Model)


Step 1 : Install Axle Drive

ITEM NO.	DESCRIPTION	QTY.
1	4 Feet Assy	1
2	Axle Drive L800	1
3	Hex Shaft L430mm	2
4	Set Screw M5	4



Step 2 : Install Side L Plate


ITEM NO.	DESCRIPTION	QTY.
1	4 Feet Assy	1
2	Side L Plate	2
3	Screw M5	8



Assembly Instruction: Install Crank Handle Assembly (4 Feet Model)


Step 1 :

ITEM NO.	DESCRIPTION	QTY.
1	4 Feet Assy	1
2	Axle Drive Holder	2
3	Axle Drive L300	1
4	Hex Shaft L175mm	1
5	Set Screw M5	1
6	Tapping Screw 5 X L30	4



Step 2 : Insert Crank Handle


ITEM NO.	DESCRIPTION	QTY.
1	4 Feet Assy	1
2	Crank Handle	1



Assembly Instruction : Install Axle Drive & Side L Plate (5 Feet Model)


Step 1 : Install Axle Drive

ITEM NO.	DESCRIPTION	QTY.
1	5 Feet Assy	1
2	Axle Drive L800	1
3	Hex Shaft L430mm	2
4	Set Screw M5	4



Step 2 : Install Side L Plate


ITEM NO.	DESCRIPTION	QTY.
1	5 Feet Assy	1
2	Side L Plate	2
3	Screw M5	8



Assembly Instruction: Install Crank Handle Assembly (5 Feet Model)

Step 1 :

ITEM NO.	DESCRIPTION	QTY.
1	5 Feet Assy	1
2	Axle Drive Holder	2
3	Axle Drive L300	1
4	Hex Shaft L175mm	1
5	Set Screw M5	1
6	Tapping Screw 5 X L30	4



Step 2 : Insert Crank Handle

ITEM NO.	DESCRIPTION	QTY.
1	5 Feet Assy	1
2	Crank Handle	1

